

WINDOW FILM ASSEMBLY SEQUENCE

- 1. Label window** (on top outside edge)
- 2. Apply double stick tape** (inside)
- 3. Stretch on the film** (inside)
- 4. Trim off excess film** (inside)
- 5. Apply double stick tape** (outside)
- 6. Stretch on the film** (outside)
- 7. Trim off excess film** (outside)
- 8. Apply 2” packing tape**
- 9. Add pull tabs**
- 10. Shrink the film**
- 11. Apply foam weather strip**